



Steps to install a Perry Luxe Kitchen Hood

1	Determine install height/location of PL hood. Mark accordingly. Remove PL liner cap and set screws aside.
2	Install exhaust fan ducting: Remove filters on exhaust fan and get electrical ready according to manufacturers instructions.
3	To install PL hood: Screw through brackets provided on the back of the PL hood and secure in place.
4	To install exhaust fan: Screw through inside of exhaust fan liner into sub framing inside of the PL hood. See exhaust fan instructions.
5	Using metal ducting tape, tape ducting from inside of exhaust fan. It must be thoroughly sealed.
6	Reinstall PL liner cap using screws provided.

3D Perspective View: Back of Hood